



SP_Flash_Tool_exe_Windows_v5.1712.00.001 upgrade instructions


1. Double-click “flash_tool.exe”, open the software.





2. Scatter-loading File: click “choose”, load file “Scatter”
Authentication File: no configuration required




3. Set: Options-Download-Storage Checksum



4. Choose the way to download "Firmware Upgrade"



5. Click "Download", turn off your device, hold USB line and battery, as below:



6. Finish as blew:

